

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



Customer _____			Registration No. _____			Odometer reading _____			00 00 119 <b>BMW Running-In Check</b> once at 1,000 km (600 miles)
Order No. _____			Date _____			Mechanic's signature _____			
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
<b>[BMW Integral ABS (partially integral), can be deactivated]</b> Conduct bleeding test with BMW Motorrad Diagnosis System								<input type="checkbox"/>	
Change engine oil								<input type="checkbox"/>	
Tighten cylinder head								<input type="checkbox"/>	
Check valve clearance and adjust if necessary								<input type="checkbox"/>	
Check secondary spark plugs								<input type="checkbox"/>	
Check brake fluid level for front brake								<input type="checkbox"/>	
Check brake fluid level for rear brake								<input type="checkbox"/>	
Check throttle cable for smooth movement, rubbing, kinks and play								<input type="checkbox"/>	
Check tire inflation pressures and tread depths								<input type="checkbox"/>	
<b>[Cross-spoke wheels]</b> check tension of spokes and tighten if necessary								<input type="checkbox"/>	
Check lighting and signal system								<input type="checkbox"/>	
Conduct operating check of engine starting interlock								<input type="checkbox"/>	
Check synchronization of throttle valve cables								<input type="checkbox"/>	
Test ride as final inspection and function check								<input type="checkbox"/>	
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
Confirm BMW Service by entry in onboard documentation								<input type="checkbox"/>	
*) Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure									

UX-VS-2, 12.2003

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



_____ Customer			_____ Registration No.			_____ Odometer reading			00 00 144  <b>BMW Service</b>  every 10,000 km (6,000 miles)
_____ Order No.			_____ Date			_____ Mechanic's signature			
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> conduct bleeding test with BMW Motorrad Diagnosis System								<input type="checkbox"/>	
Change engine oil								<input type="checkbox"/>	
Check valve clearance and adjust if necessary								<input type="checkbox"/>	
Check secondary spark plugs								<input type="checkbox"/>	
Check hydraulic clutch system								<input type="checkbox"/>	
Check front brake disks for wear								<input type="checkbox"/>	
Check front brake pads for wear								<input type="checkbox"/>	
Check brake fluid level for front brake								<input type="checkbox"/>	
Check rear brake disk for wear								<input type="checkbox"/>	
Check rear brake pads for wear								<input type="checkbox"/>	
Check brake fluid level for rear brake								<input type="checkbox"/>	
Check throttle cable for smooth movement, rubbing, kinks and play								<input type="checkbox"/>	
Check tire inflation pressures and tread depths								<input type="checkbox"/>	
<b>[Cross-spoke wheels]</b> check tension of spokes and tighten if necessary								<input type="checkbox"/>	
Check side support for smooth movement								<input type="checkbox"/>	
Check side stand for smooth movement								<input type="checkbox"/>	
Check lighting and signal system								<input type="checkbox"/>	
Conduct operating check of engine starting interlock								<input type="checkbox"/>	
Check synchronization of throttle valve cables								<input type="checkbox"/>	
Test ride as final inspection and function check								<input type="checkbox"/>	
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
Confirm BMW Service by entry in onboard documentation								<input type="checkbox"/>	
*) Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure									

UX-VS-2, 12.2003

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



_____ Customer Registration No. Odometer reading			<b>00 00 146</b> <b>BMW Service with BMW Annual Inspection</b> <b>annually, every 10,000 km (6,000 miles)</b>
_____ Order No. Date Mechanic's signature			
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
Change engine oil			<input type="checkbox"/>
Check valve clearance and adjust if necessary			<input type="checkbox"/>
Check secondary spark plugs			<input type="checkbox"/>
Check hydraulic clutch system			<input type="checkbox"/>
Check front brake disks for wear			<input type="checkbox"/>
Check front brake pads for wear			<input type="checkbox"/>
Check rear brake disk for wear			<input type="checkbox"/>
Check rear brake pads for wear			<input type="checkbox"/>
<b>[not for BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of wheel circuits			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of control circuits <sup>*)</sup> every 2 years			<input checked="" type="checkbox"/>
Check throttle cable for smooth movement, rubbing, kinks and play			<input type="checkbox"/>
Check tire inflation pressures and tread depths			<input type="checkbox"/>
<b>[Cross-spoke wheels]</b> check tension of spokes and tighten if necessary			<input type="checkbox"/>
Check side support for smooth movement			<input type="checkbox"/>
Check side stand for smooth movement			<input type="checkbox"/>
Check lighting and signal system			<input type="checkbox"/>
Conduct operating check of engine starting interlock			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> conduct bleeding test with BMW Motorrad Diagnosis System			<input type="checkbox"/>
Check synchronization of throttle valve cables			<input type="checkbox"/>
Test ride as final inspection and function check			<input type="checkbox"/>
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
Charge AGM (Absorptive Glass Matt) battery			<input type="checkbox"/>
Confirm BMW Service by entry in onboard documentation			<input type="checkbox"/>
<sup>*)</sup> Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure			

UX-VS-2, 12.2003

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



Customer _____	Registration No. _____	Odometer reading _____	00 00 149 <b>BMW Inspection</b> every 20,000 km (12,000 miles)
Order No. _____	Date _____	Mechanic's signature _____	
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> conduct bleeding test with BMW Motorrad Diagnosis System			<input type="checkbox"/>
Change engine oil			<input type="checkbox"/>
Change gear oil <sup>*)</sup> <b>every 40,000 km (24,000 miles)</b>			<input checked="" type="checkbox"/>
Check valve clearance and adjust if necessary			<input type="checkbox"/>
Check secondary spark plugs <b>for first time at 20,000 km (12,000 miles), then every 40,000 km (24,000 miles)</b>			<input checked="" type="checkbox"/>
Replace spark plugs <sup>*)</sup> <b>every 40,000 km (24,000 miles)</b>			<input checked="" type="checkbox"/>
Replace intake air filter element			<input type="checkbox"/>
Replace alternator drive belt <sup>*)</sup> <b>every 60,000 km (36,000 miles)</b>			<input checked="" type="checkbox"/>
Check hydraulic clutch system			<input type="checkbox"/>
Check front brake disks for wear			<input type="checkbox"/>
Check front brake pads for wear			<input type="checkbox"/>
Check brake fluid level for front brake			<input type="checkbox"/>
Check rear brake disks for wear			<input type="checkbox"/>
Check rear brake pads for wear			<input type="checkbox"/>
Check brake fluid level for rear brake			<input type="checkbox"/>
Check throttle cable for smooth movement, rubbing, kinks and play			<input type="checkbox"/>
Check tire inflation pressures and tread depths			<input type="checkbox"/>
<b>[Cross-spoke wheels]</b> check tension of spokes and tighten if necessary			<input type="checkbox"/>
Check side support for smooth movement			<input type="checkbox"/>
Check side stand for smooth movement			<input type="checkbox"/>
Check lighting and signal system			<input type="checkbox"/>
Conduct operating check of engine starting interlock			<input type="checkbox"/>
Check synchronization of throttle valve cables			<input type="checkbox"/>
Test ride as final inspection and function check			<input type="checkbox"/>
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
Charge AGM (Absorptive Glass Matt) battery			<input type="checkbox"/>
Confirm BMW Service by entry in onboard documentation			<input type="checkbox"/>
<sup>*)</sup> Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure			

UX-VS-2, 12.2003

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



_____ Customer			_____ Registration No.			_____ Odometer reading			<b>00 00 155</b> <b>BMW Annual</b> <b>Inspection</b> <b>annually</b>
_____ Order No.			_____ Date			_____ Mechanic's signature			
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
Change engine oil								<input type="checkbox"/>	
Change gear oil *) <b>every 2 years</b>								<input type="checkbox"/>	
<b>[not for BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid								<input type="checkbox"/>	
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of wheel circuits								<input type="checkbox"/>	
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of control circuits *) <b>every 2 years</b>								<input checked="" type="checkbox"/>	
<b>[BMW Integral ABS (partially integral), can be deactivated]</b> Conduct bleeding test with BMW Motorrad Diagnosis System								<input type="checkbox"/>	
Check throttle cable for smooth movement, rubbing, kinks and play								<input type="checkbox"/>	
Check tire inflation pressures and tread depths								<input type="checkbox"/>	
Check lighting and signal system								<input type="checkbox"/>	
Conduct operating check of engine starting interlock								<input type="checkbox"/>	
Test ride as final inspection and function check								<input type="checkbox"/>	
Read the fault-code memory with the BMW Motorrad diagnosis system								<input type="checkbox"/>	
Charge AGM (Absorptive Glass Matt) battery								<input type="checkbox"/>	
Confirm BMW Service by entry in onboard documentation								<input type="checkbox"/>	
*) Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure									

UX-VS-2, 12.2003

# BMW Motorrad Maintenance Schedule R 1200 GS 0307 / 0317



			00 00 157
			<b>BMW Inspection with BMW Annual Inspection</b>
Customer	Registration No.	Odometer reading	<b>annually, every 20,000 km (12,000 miles)</b>
Order No.	Date	Mechanic's signature	
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
Change engine oil			<input type="checkbox"/>
Change gear oil *) <b>every 40,000 km (24,000 miles)/ every 2 years</b>			<input checked="" type="checkbox"/>
Check valve clearance and adjust if necessary			<input type="checkbox"/>
Replace spark plugs *) <b>every 40,000 km (24,000 miles)</b>			<input checked="" type="checkbox"/>
Check secondary spark plugs <b>for first time at 20,000 km (12,000 miles), then every 40,000 km (24,000 miles)</b>			<input checked="" type="checkbox"/>
Replace intake filter			<input type="checkbox"/>
Replace alternator drive belt *) <b>every 60,000 km (36,000 miles)</b>			<input checked="" type="checkbox"/>
Check hydraulic clutch system			<input type="checkbox"/>
Check front brake disks for wear			<input type="checkbox"/>
Check front brake pads for wear			<input type="checkbox"/>
Check rear brake disk for wear			<input type="checkbox"/>
Check rear brake pads for wear			<input type="checkbox"/>
<b>[not for BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of wheel circuits			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral, can be deactivated)]</b> change brake fluid of control circuits *) <b>every 2 years</b>			<input checked="" type="checkbox"/>
Check throttle cable for smooth movement, rubbing, kinks and play			<input type="checkbox"/>
Check tire inflation pressures and tread depths			<input type="checkbox"/>
<b>[Cross-spoke wheels]</b> check tension of spokes and tighten if necessary			<input type="checkbox"/>
Check side support for smooth movement			<input type="checkbox"/>
Check side stand for smooth movement			<input type="checkbox"/>
Check lighting and signal system			<input type="checkbox"/>
Conduct operating check of engine starting interlock			<input type="checkbox"/>
<b>[BMW Integral ABS (partially integral), can be deactivated]</b> Conduct bleeding test with BMW Motorrad Diagnosis System			<input type="checkbox"/>
Check synchronization of throttle valve cables			<input type="checkbox"/>
Test ride as final inspection and function check			<input type="checkbox"/>
Read the fault-code memory with the BMW Motorrad diagnosis system			<input type="checkbox"/>
Charge AGM (Absorptive Glass Matt) battery			<input type="checkbox"/>
Confirm BMW Service by entry in onboard documentation			<input type="checkbox"/>
*) Invoiced as separate items <input type="checkbox"/> Not part of standard service procedure			

UX-VS-2, 12.2003